


Hướng dẫn cấu hình internet modem TP-Link TD-W8951ND

I. Hình ảnh modem

Hình dáng và các tín hiệu đèn (lưu ý các đèn trên modem không ghi tên)



Hình dáng modem:



II. Hướng dẫn cấu hình:

Mở trình duyệt web, nhập vào địa chỉ modem mặc định <http://192.168.1.1>

Đăng nhập bằng user/pass mặc định : admin/admin.

Chọn Interface Setup → Internet và cấu hình các thông số như hình dưới.

Bấm Save để lưu cấu hình, hoàn tất.

Interface Quick Start **Interface Setup** Advanced Setup Access Management Maintenance Status Help

Internet LAN Wireless

ATM VC

Virtual Circuit : PVC0 PVCs Summary

VPI : 0 (range: 0~255)

VCI : 33 (range: 1~65535)

QoS

ATM QoS : UBR

PCR : 0 cells/second

SCR : 0 cells/second

MBS : 0 cells

Encapsulation

ISP : Dynamic IP Address
 Static IP Address
 PPPoA/PPPoE
 Bridge Mode

PPPoE/PPPoA

Servicename : Internet

Username : hndsl-inf4

Password :

Encapsulation : PPPoE LLC

Bridge Interface : Activated Deactivated

Username và password từ nhà cung cấp

Connection Setting

Connection : **Always On (Recommended)**
 Connect On-Demand (Close if idle for 0 minutes)
 Connect Manually

TCP MSS Option : TCP MSS(default:1400) 1400 bytes

IP Address

Get IP Address : Static Dynamic

Static IP Address : 0.0.0.0

IP Subnet Mask : 0.0.0.0

Gateway : 0.0.0.0

NAT : Enable

Default Route : Yes No

TCP MTU Option : TCP MTU(default:1480) 1480 bytes

Dynamic Route : RIP2-B Direction : Both

Multicast : Disabled

SAVE